Monkey IFN-γ ELISpot^{PRO}

Product Code: 3420M-2APT-2

CONTENTS:

Pre-coated plates, mAb GZ-4 (2 clear plates)

7-B6-1-ALP conjugate (150 µl)

BCIP/NBT-plus substrate (25 ml)

Positive control anti-CD3 mAb CD3-1 (100 µl)

STORAGE:

Shipped at ambient temperature. On arrival all reagents should be stored refrigerated at 4-8°C. Plates may be kept at room temperature. Conjugate is supplied in 0.1M Tris buffer with 0.002% Kathon CG. CD3-1 is supplied in sterile filtered (0.2 μ m) PBS. Vials have been overfilled to ensure recovery of stated quantity.

Guidelines for Monkey IFN- γ ELISpot^{PRO} Please read through before starting the assay

A Preparation and blocking of plate

- 1. Remove the plate from the sealed package and wash 4 times with sterile PBS (200 µl/well).
- 2. Condition the plate with medium containing 10% of the same serum as used for the cell suspensions (200 µl/well). Incubate for at least 30 minutes at room temperature.

B Incubation of cells in plate

- 1. Remove the medium and add the stimuli followed by the cell suspension. Alternatively cells and stimuli can be mixed before addition to the plate. The mAb CD3-1, included in the kit, is recommended as a positive control for cytokine production in a dilution of 1:1000.
- 2. Put the plate in a 37°C humidified incubator with 5% CO_2 and incubate for 12-48 hours. Do not move the plate during this time and take measures to avoid evaporation (e.g. by wrapping the plate in aluminium foil).

C Detection of spots

- 1. Remove the cells by emptying the plate and wash 5 times with PBS, $200 \,\mu$ l/well.
- 2. Dilute the 7-B6-ALP 1:200 in filtered PBS containing 0.5% fetal calf serum. Add 100 μ l to each well and incubate for 2 hours at room temperature.
- 3. Wash the plate 5 times with PBS, $200 \,\mu$ l/well.
- 4. Filter the ready-to-use substrate solution (BCIP/NBT-plus) through a 0.45 μm filter and add 100 μl of substrate per well. Develop until distinct spots emerge. Stop the colour development by washing extensively in tap water. If desirable, remove the underdrain (the soft plastic under the plate) and rinse the underside of the membrane.
- 5. Leave the plate to dry. Inspect and count spots in an ELISpot reader or in a dissection microscope.
- 6. Store plate in the dark at room temperature.

Hints and comments

These suggestions are based on the detection of antigen-specific immune responses using PBMC. If using T-cell clones, mixtures of separated cell fractions etc., other protocols may have to be considered.

Plate washing

Washing of plates can be done using a multi-channel micropipette. In washing steps not requiring sterile conditions (C1-C5), a regular ELISA plate washer can also be used, provided that the washing head is adapted to the ELISpot plates. Avoid getting liquid on the underside of the membrane as this may cause leakage due to capillary drainage.

Cells

Both freshly prepared and cryopreserved cells may be used in the assay. However it is recommended that the latter are rested for at least one hour to allow removal of cell debris before addition to the plate. Triplicates or duplicates of 250,000 cells per well are often used to assess antigen-specific responses. For polyclonal activators, the cell number may have to be reduced to avoid confluent spot formation. Protocols with other incubation times have to be established by the user.

Serum

The serum should be selected to support cell culture and give low background staining. We recommend the use of fetal calf serum. Alternatively serum-free medium evaluated for cell culture can be used.

Conjugate

To reduce unspecific background it is recommended to filter the detection mAb-enzyme conjugate $(0.2 \ \mu m)$.

Assay controls

The number of cells responding to stimulation is often compared to the number of cells spontaneously producing the cytokine, which is determined by incubating the same number of cells in the absence of stimuli. A polyclonal activator such as the included anti-CD3 mAb, CD3-1 or phytohemagglutinin (1-10 μ g/ml) is often used as a control for cell viability and functionality of the test system.

Buffers

PBS for washing and dilution should be filtered (0.2 μ m) for optimal results. Avoid the inclusion of Tween or other detergents in the washing and incubation buffers.

Substrate development

Develop until distinct spots are visible in positive wells (usually 10-30 minutes). A general darkening of the membrane may occur but disappears after drying.

MABTECH AB Augustendalsvägen 19 Box 1233, SE-131 28 Nacka Strand Sweden Tel: +46 8 716 27 00 Fax: +46 8 716 27 01 E-mail: mabtech@mabtech.com

MABTECH Inc M.E.B. 220, 3814 West Street Cincinnati, OH 45227 USA Toll free: +1 866 ELI-SPOT Tel: +1 513 871 4500 Fax: +1 513 871 7353 E-mail: mabtech.usa@mabtech.com

MABTECH AUSTRALIA Pty Ltd Australia Tel: +61 3 9470 4704 Fax: +61 3 8678 3216 E-mail: mabtech.au@mabtech.com

MABTECH AB Büro Deutschland Germany Tel: +49 40 4135 7935 Fax: +49 40 4135 7945 E-mail: mabtech.de@mabtech.com

MABTECH AB Bureau de liaison France Tel: +33 (0)4 92 38 80 70 Fax:+33 (0)4 92 38 80 71 E-mail: mabtech.fr@mabtech.com

Updated on 2015-02-23

MABTECH

NOTE; for research use only.

MABTECH shall not be liable for the use or handling of the product or for consequential, special, indirect or incidental damages therefrom.



Developed and manufactured by MABTECH AB, Sweden, whose quality management system complies with the above standards.

For more information about Mabtech services and our products, visit

www.mabtech.com